

## P04F0 - EVAP System High Load Purge Line A Performance

**Description:** The EVAP check valve test is performed during minimal boost conditions, once per drive cycle, when entry conditions are met. This DTC sets when the fuel tank pressure exceeds a calibrated amount within a specified amount of time during the test.

**Possible Causes:**

- Restricted EVAP ejector connections at the intake air system
- Stuck open EVAP check valve
- Stuck closed EVAP check valve
- Damaged EVAP ejector
- Damaged EVAP check valve

### Diagnostic Aids:

| Application | Key On Engine Off                        | Key On Engine Running | Continuous Memory |
|-------------|------------------------------------------|-----------------------|-------------------|
| All         | GO to Pinpoint Test <a href="#">HX</a> . |                       |                   |

